
# **Charger Cable**

# CONTENT



### **IMPORTANT NOTICE**

· Contact the place of purchase or a distributor for information on installation, adjustment, and replacement of the products which are not found in the user's manual. A dealer's manual for professional and experienced bicycle mechanics is available on our website (https://www.darfonenergy.com/tw/).

For safety, be sure to read this "user's manual" thoroughly before use, follow it for correct use, and store it so that it can be referenced at any time.

• The following instructions must be observed at all times in order to prevent personal injury and physical damage to equipment and surroundings. The instructions are classified according to the degree of danger or damage which may occur if the product is used incorrectly.

▲ DANGER	Failure to follow the instructions will result in death or serious injury.	
▲ WARNING	Failure to follow the instructions could result in death or serious injury.	
▲ CAUTION	Failure to follow the instructions could cause personal injury or physical damage to equipment and surroundings.	

# **IMPORTANT SAFETY INFORMATION**




• Do not disassemble or modify the product. This may cause the product not to operate correctly, and you may thus get injured.

#### NOTICE


- · Ensure the nut is tightened.
- Do not pin the wire cable or pull it with excessive force.

# **INSTALL THE CHARGER CABLE**


· Release the nut and take it out.




Ensure the charger cable passes through the frame tube.




· Set in the nut from the connector side.



· Tighten the nut to the frame.



 Match the connector on the button cable with the corresponding connector on the mount.



# **TROUBLESHOOTING**

Details	Causes / possibilities	Remedy
Button malfunction	<ul><li>Wire broken?</li><li>Connector loosing?</li><li>Foreign matter inside the button?</li></ul>	<ul><li>Contact the place of purchase.</li><li>Install the connector again.</li><li>Clean the area around button.</li></ul>
Button loosing	Nut not sufficiently tightened.	Install the nut again.











7 F., No. 167-1, Shanying Rd., Guishan Dist., Taoyuan City 333017, Taiwan (R.O.C.)

#### Darfon Electronics Czech s.r.o

Cyrcovice 192, 691 23 Cyrcovice. Czech Republic.

Please note: specifications are subject to change for improvement without notice. (English) © May 2024 by Darfon Energy Technology Corp.

